



H2O Dual Buff™ USER GUIDE

Thank you for purchasing the H2O Dual Buff™, All-In-One Steam Mop Head, Floor Polisher and Scrubber!

This product is designed to be used with the **H2O HD™ Steam Cleaner** for cleaning sealed hard floors with smooth surfaces only.

IMPORTANT: Please read the contents of this User Guide before first use and always follow all Instructions and Warnings in the Manual supplied with the H2O HD™ Steam Cleaner.

Scan this QR code to access the H2O HD™ Manual.



Included:

- 1 x H2O Dual Buff™ unit
- 1 x USB-C to USB-A cable
- 2 x Cleaning Pad

Optional accessory:

H2O Dual Buff™ Scrubbing Pad*

*To order H2O Dual Buff™ scrubbing pads please contact the customer service or website where you purchased your unit from.

Specifications:

- Model #: KB-068
- Li-ion Battery: 11.1 V, 1500 mAh, 16.65 Wh
- DC Input: 5V 2A
- Rated Power: 72 W
- Household Use Only

How to Charge H2O Dual Buff™

1. Make sure to charge the unit fully before first use. The full charge time is around 2.5 - 4 hours.
2. Connect the USB-C connector to the charging port on the unit and plug in the USB-A connector into a 5V 2A rated USB Wall Charger. The Battery Light Indicator will turn red while charging. When the unit is fully charged the Battery Light Indicator will turn green.
3. Once the charging is done, unplug the cable from the charging port on the H2O Dual Buff™

NOTE: When the battery power is low the Battery Light Indicator will start flashing red to warn you to charge the battery.

WARNINGS:

- **Never use the H2O Dual Buff™ unit while it is charging!**
- **Avoid charging or storing the H2O Dual Buff™ unit at high temperatures greater than 120°F (50°C). High temperatures might ignite the battery and cause a fire. Avoid charging lithium batteries below freezing (32°F or 0°C), as this will permanently reduce the battery capacity.**

NOTE: The average charging time for this product will vary based on the type of charger and power source used.

How to attach H2O Dual Buff™ to H2O HD™ Steam Mop

1. Take the H2O Dual Buff™ Cleaning Pads and attach them to the two round discs located at the bottom of the H2O Dual Buff™ unit. Press and fit together ensuring a snug fit. (fig. 1)






FIG. 1

2. Remove the triangle Mop Head from your H2O HD™ Steam Cleaner by unscrewing the mop head screw located on the back side of the Main Body's lower portion and then pull the triangle Mop Head straight down away from your H2O HD™ Main Body. Make sure not to displace the mop head screw, you will need it to fix the H2O Dual Buff™ head to the H2O HD™ Main Body (fig. 2)



3. Insert the black connector of the H2O Dual Buff™ unit into the H2O HD™ steam mop body, then insert and tighten the screw. Note: use the same mop head screw removed from the H2O HD™ body in step 2 above. Attach the H2O™ HD Mop Head, then insert and tighten the provided screw into the hole on the back (screwdriver not included).

How to use H2O Dual Buff™

For Cleaning with Steam

Follow Instructions for H2O HD™ Steam Cleaner how to release steam and operate the steam mop. Press the On/Off button on the H2O Dual Buff™ unit to start the dual disc with Cleaning Pads spinning. Mop with a forward and backward motion. When finished mopping press the On/Off button on the H2O Dual Buff™ unit. To stop emitting steam follow instructions how to operate the H2O HD™ Steam Cleaner

For Dry Buffing

Make sure to use dry and clean H2O Dual Buff™ Cleaning Pads. Press the On/Off button on the H2O Dual Buff™ unit to start the dual disc with Cleaning Pads spinning. Buff with a forward and backward motion.

NOTE: It is not required to plug in the H2O HD™ Steam Cleaner for this operation.

IMPORTANT: The H2O Dual Buff™ is equipped with a motor overload protection device.

This safeguard device protects the motor from overheating and damage when too much pressure is applied on the rotating discs. When it happens the unit will stop working and the Battery Light Indicator will start flashing green. To continue cleaning reduce the pressure on the rotating discs and press the On/Off button to start the rotating discs working again.


Cleaning Pads care:

- Machine wash at 104 F (40 C)
- Do not bleach
- Do not use fabric softener

Loose fibers can indicate wearing of the Cleaning Pads. For best cleaning results we recommend replacing the Cleaning Pads every 3 - 4 months.

Correct Disposal of This Product

This product contains Lithium-ion batteries. Products containing Lithium-ion batteries should NOT go in household garbage or recycling bins. This product should be taken to separate recycling or household hazardous waste collection points for disposal.



Distributed by:

Thane Canada Inc.
2680 Skymark Avenue, Unit 110, Mississauga ON L4W 5L6, Canada
www.thane.ca

Thane USA, Inc.
4050 Whipple Ave. NW, #31, Canton, OH 44718, U.S.A.
www.thane.com

Thane Direct UK Limited
3 Acorn Business Centre, Northarbour Road, Portsmouth, PO6 3TH
www.thanedirect.eu

© 2024 Thane IP Limited.

"THANE", "H2O", "H2O Dual Buff", "H2O HD" and related logos and variations are trademarks or registered trademarks, in Canada and/or other countries, of Thane IP Limited and/or its affiliated companies.